

21—85.18 (215) Weight capacity. The amount of weight indicated on the beam, dial or other auxiliary weighing attachments shall not exceed the factory-rated capacity of the scale, and said capacity shall be stamped on the butt of the beam (fractional bar is not included).

85.18(1) Auxiliary attachment. If auxiliary attachment is used, the amount of the auxiliary attachment must be blocked from the beam.

85.18(2) Normal position. The normal balance position of the weighbeam of a beam scale shall be horizontal.

85.18(3) Travel. Rescinded IAB 3/31/04, effective 5/5/04.

85.18(4) Weighbeam. Rescinded IAB 3/31/04, effective 5/5/04.

85.18(5) Poise stop. Rescinded IAB 3/31/04, effective 5/5/04.

85.18(6) Pawl. Rescinded IAB 3/31/04, effective 5/5/04.

85.18(7) Nominal capacity, marking. Rescinded IAB 3/31/04, effective 5/5/04.

85.18(8) Uncompensated spring scales. A small capacity uncompensated spring scale shall be conspicuously marked to show that the scale is illegal for use in the retail sale of foodstuffs other than fruits and vegetables.

This rule is intended to implement Iowa Code section 215.16.